



WANDA- THE MOST PRODUCTIVE AND LABOUR SAVING WAY OF TUFTING



Working procedure: The cushions are placed on a conveyor between two HECTOR standard machines, placed opposite each other. Via a photocell the cushions are fed into position and the tufting takes place automatically.

The HECTOR machines are mounted on wheels, which make them easy to pull apart for service and change of bobbins. The needle distance between the sewing heads can be set between 15,5 and 20,0 cm. The computer can hold several patterns. Normal working rate is 8 couples of tuftings per minute. WANDA can be combined with the CROSSLINE 100

Standard equipment: Conveyor 4x0,5 m with 3 grip bands 9 cm wide.
Thread guard for the upper thread.

Alternative: Manual version TWIN without conveyors

STYRTEKNIK EUROPE AB

Florettgatan 11, S-254 67 Helsingborg, Sweden Tel +46 (042) 158585 Telefax +46 (042) 201470
www.styrteknik.com E-mail info@styrteknik.com



Working procedure: The cushions are placed on a conveyor between two HECTOR standard machines, placed opposite each other. Via a photocell the cushions are fed into position and the tufting takes place automatically.

The HECTOR machines are mounted on wheels, which make them easy to pull apart for service and change of bobbins. The needle distance between the sewing heads can be set between 16,5 and 20,0 cm. The computer can hold several patterns. Normal working rate is 8 couples of tuftings per minute. WANDA can be combined with the CROSSLINE 100

Standard equipment: Conveyor 4x0,5 m with 3 grip bands 9 cm wide.

Thread guard for the upper thread.

Alternative: Manual version TWIN without conveyors

STYRTEKNIK EUROPE AB

Florettgatan 11, S-254 67 Helsingborg, Sweden Tel +46 (042) 158585 Telefax +46 (042) 201470

www.styrteknik.com E-mail info@styrteknik.com